

## DISC OF TRON

## OPTION SWITCH SETTINGS

/////////////////SWITCH NO. 1 - AT B 3 - LOCATED ON SOUND I/O P.C. BOARD/////////////////

DURING GAME PLAY:	SW#1 NOT USED	SW#2 NOT USED	SW#3 NOT USED	SW#4 NOT USED	SW#5 NOT USED	SW#6 NOT USED	SW#7	SW#8 NOT USED	SW#9 NOT USED	SW#10
UPRIGHT MINI COCKTAIL TABLE								ON		
FREEZE VIDEO ** NORMAL OPERATION								OFF		
										ON
										OFF

/////////////////SWITCH NO. 3 - AT D 14 - LOCATED ON SOUND I/O P.C. BOARD/////////////////

	SW#1 OFF	*SW#2 ON	*SW#3	*SW#4
** NORMAL OPERATION SOUND I/O DIAGNOSTIC MODE				
** NORMAL OPERATION RAM/ROM TEST INDICATES TEST RESULTS VIA YELLOW LED ON SOUND I/O BOARD: FAST FLASH = BAD ROM SLOW FLASH = BAD RAM		OFF		ON
** NORMAL OPERATION OSCILLATOR TEST			OFF	
** NORMAL OPERATION FILTER TEST			ON	
* NO EFFECT IF SW#1 OF SWITCH NO. 3 IS IN THE "OFF" POSITION.				
** FACTORY RECOMMENDED SETTINGS.				
				PART NO. M051-00383-A007

THE REMAINDER OF YOUR NEW GAME'S MOST COMMON OPTION SETTINGS ARE CONDUCTED DURING THE  
MACHINE SETUP PORTION OF THE SELF-TEST MODE AND WILL BE COVERED IN DETAIL  
IN THAT SECTION OF YOUR MANUAL.